


# FIRE/WATER CHEST USER MANUAL

# KARBON

SECURITY



## OPENING

1. Undo clasp
2. Insert key into the key lock and turn counterclockwise to unlock (if key lock is in use)
3. Lift the lid to open

## CLOSING

1. Close the lid
2. Insert key into the key lock and turn clockwise to lock (Note: Using the key lock is optional)
3. Close the clasp

