

	1	1	Г
EXCALIBUR ASSEMBLY INSTRUCTIONS	E4*6	E6*2	E2*2
Warning: Only for domestic outdoor use. This outdoor play set satisfies all the requirements of the European standard EN 71 and has been certified by an independent laboratory. To guarantee safety, please give special attention to the assembly, safety, and care instructions detailed in this document.			
Safe & Suitable Use: - This product must not be used by children under 36 months. It is only for children aged from 3 to 12 years with a maximum weight of 50kg. It must be	Ø8*60	Ø8*65	Ø
used under adult supervision. - The EN 71-8, chapter 4-6 standard requires a 35cm minimum distance between the ground and swings. These distances are important for safe use.	J14*8	E28*2	J5*2
After having assembled the playground, check these distances. In case of non-conformity, do not hesitate to contact our after sales service. - This product is only for private use at home and must never be used in parks and public gardens, in schools, camp sites, hotels, public leisure areas,			
etc - The product should be set up on a flat surface and 2 metres away from all other things, structures or obstacles (walls, fences, trees, washing lines or		~ 0	
electric cables, etc) that could cause injury during use. - As this product contains small parts that could be swallowed, please keep parts away from children under 36 months.			
This product should not be installed over concrete, asphalt or any other hard surface. Any modifications made by the consumer to this play set should be carried out according to the instructions of the manufacturer.	Ø6*40	Ø6*25	Ø
- Please note that this play set contains Timber, a natural product, and as such should be checked for any rough surfaces before use, if required these should be lightly sanded in order to prevent injury	E20*14	E3*16	E14*8
Dispose of packaging thoughtfully. Do not allow children to play with packaging.			
CAUTION ! This Product Contains Timber, Please Keep away from fire.			6
Make Regular Safety Checks	Ø6*63	Ø6*58	Ø
Safety checks should be carried out regularly on this product. These checks should include, if necessary, removing any sharp edges, replacing missing screw covers, and tightening the nuts and bolts. These checks should be done to avoid any danger through normal wear and tear.	D7*4	D6*4	C18*2
Assembly Advice:	(]		
Please follow the assembly instructions exactly as given. - This product must be assembled by an adult.	a		Coll
- Keep a copy of your assembly instructions for future reference. This can be particularly handy for identification of parts if any after sales service is required.			
 Pre-Drill timber before fixing with screws to avoid cracks in the timber. For all of our products equipped with a slide, we advise that the slide is not faced towards the sun. 	A4*1	10\13	D2*8
Maintenance Advice:			
 The timber used in this product is pine. It is FSC certified and it is treated by autoclave (ACQ). All parts should be checked at least once a month. 			
- In certain regions (seaside areas), certain coatings could be prone to damage. In this case, it is advised to use a rust prevention treatment. - If the hooks on the over head beam show wear over 10% of the initial thickness, they should be replaced by the exact same fixtures as were originally			
provided. - All parts that are under constant friction should be oiled regularly using a suitable lubricant.	B85*4	B114*1	1
- It is recommended that during the winter period when the equipment is not in use, all apparatus are removed to prevent deterioration due to bad weather.		E.T.	
- The ground on which the product is placed should be controlled regularly. All elements such as stones or other objects that could cause injury in the case of a fall, should be removed.			· · · ·
- For aesthetic reasons, you may want to apply a timber treatment to the timber parts.			
FIXING INTO THE GROUND IMPORTANT ! For safety reasons, your play set must be embedded into the ground. - Place your play set in the desired position and mark a square area 250mm x 250 mm around each of the feet. Dig holes 300 mm deep. (The feet must	B151*1	B52*3	
 Place your play set in the desired position and mark a square area 250mm x 250 mm around each of the feet. Dig holes 500 mm deep. (The feet must be in the center of the square) Fill the holes with concrete. Do not exceed the ground level. Fit the embedding piece into the center of the concrete so that fixtures for screwing the 	11	· · · · ·	B
 Fin the holes with concrete. Do not exceed the ground level. Fit the embedding piece into the center of the concrete so that fixtures for screwing the posts into place rise out of the concrete. When the concrete is dry, screw the posts to the embedding pieces. 	0	•	
- Anchors should be placed level with or below ground level in order to reduce tripping hazards.	D150*1	DC4*4	
IMPORTANT ! Wait until the concrete is set before using the play set and check anchorages regularly.	B152*1	B64*1	
Please keep the additional components - they may be useful for future operation and maintenance.	r.t.		1
CAUTION ! Fall danger. Dimensions given are indicative only. They may vary according to the assembly method.			
CAUTION ! This product contains small parts that could be swallowed.	B119*2	B62*4	
SWING			
SLIDE CLIMB			
Customer Support: (03) 9786 0055	H88*2	H183*1	
14*1 K5*1 18*2 C24*1 C40*1			705+0/
		1055*50*45	795*90
	H184*2	H29*2	
	:	730*90*22	730*90

-





804027_IM_12B.indd 2